

APESIN activdes hygiene



Disinfecting washing powder

- Broad spectrum
- Proven performance
- Disinfection at 60 °C

Product profile

- APESIN activdes hygiene is a disinfecting washing powder detergent with a broad activity spectrum specially designed for professional laundries. It washes, bleaches and disinfects all in once.
- Protein and starch stains and unpleasant odors will be eliminated.
- APESIN activdes hygiene assures a hygienic laundry disinfection meeting professional standards and requirements of the Biocidal Products Directive.
- Its disinfection properties have been tested according to EU standards (DIN EN) in compliance with Biocidal Product Regulation EU Nr. 528/2012 and listed according to the guidelines of the DGHM/VAH as well as RKI list. It has biocidal activity according to EN 13727, EN 16616 and EN 14476 respectively.
- For dosing instructions see following page.

Area of application

- Suitable for all types of washing machines, temperatures and water hardnesses.
- APESIN activdes hygiene has been designed to wash all white textiles excepting wool and silk.

Ingredient declaration:

Ingredients per 100g: >2g peracetic acid generated in situ from sodium percarbonate and TAED, 15 - 30% oxygen-based bleaching agents, 5 - 15% zeolites, <5% phosphonates, anionic surfactants, non-ionic surfactants, polycarboxylates, soap, optical brighteners, perfumes.

Sustainable development and production:



Product safety, storage and environmental instructions

Safety: For professional use only. For further information, see Safety Data Sheet. Use biocides safely. Always read the label and product information before use.

Storage: Store at room temperature (5 to 35°C) in the original container.

Environmental: Only give completely emptied packaging to special waste disposer.

Application and Dosing



Dose in relation to application and degree of soil. Follow below instructions.

Sales Unit:

Order No.: 715040 1 x 15 kg

Your trusted partner on site

pH-Value 1%:













APESIN activdes hygiene



Disinfecting washing powder

Bactericidal, fungicidal, mykobactericidal and virucidal activity	Concentration	Liquor ratio (kg dry laundry / L)	Disinfection-temperature	Contact time	Quantity in g/kg dry laundry
EN 13727	5 g/l	–	60 °C	15 min	–
EN 16616	5 g/l	1 : 5	60 °C	15 min	25 g/kg
EN 14476	5 g/l	–	60 °C	15 min	–
RKI-Listing					
according §18 IfSG, scope AB *	5 g/l	1 : 5	60 °C	20 min.	25 g/kg
*not suitable for laundry noticeably contaminated with blood					
VAH - Certificate					
chemothermal linen disinfection procedure	5 g/l	1 : 5	60 °C	15 min.	25 g/kg

*/kg			
	15 ml*	33 ml*	43 ml*
	12 g*	25 g*	35 g*
	16 ml*	33 ml*	47 ml*
	13 g*	27 g*	38 g*
	17 ml*	36 ml*	51 ml*
		11 g*	25 g*
		15 ml*	33 ml*

*BPR: The Biocidal Products Regulation is valid from 2013. This regulation aims to improve the functioning of biocidal products market in the EU. For further information, please contact: info.professional@werner-mertz.com

